

# DMX-Fix User Guide

(Version 1.4)

DMX-Fix is a combined DMX512 error fixer and splitter. It is used to solve compatibility problems between DMX512 devices.

## Key Features include:

- ❑ Input Optical Isolation
- ❑ Five independent outputs, All connections via Neutrik XLR
- ❑ DMX512-A compatible
- ❑ Truss Mounting adaptor available
- ❑ Fixed DMX512 output timing:
  - Break: 250uS
  - MaB: 30uS
  - MbB: 30uS
  - Channels: 512
  - Refresh: 30mS
- ❑ Removes all advanced data with non zero start codes such as RDM and SIPs
- ❑ Retimes DMX512 input and corrects both byte and break timing
- ❑ Last Frame Transmit on DMX input failure

## Specification:

Input Voltage: 9V DC  
Maximum Current: 0.5 A  
Dimensions: W:195mm H:115mm D:55mm  
Mounting: Free standing or Truss Mounted (optional adaptor)  
IP: Indoor use only  
Listings: CE, FCC

## Power Supply Options: (order separately)

PSU-9-1.5-XLR4  
Output: 9V 1.5A  
Max DMX-Splits: 1  
Connection: 4pin Female XLR  
Listing: CE / FCC / UL / PSE



Copyright © Artistic Licence Engineering Ltd. All rights reserved.

## DMX512 Wiring:

XLR Pin	Function	Colour
1	Ground	Black
2	Data -	Blue
3	Data +	Red
4	No Connection	
5	No Connection	


## Power Input Wiring:

XLR Pin	Function	Colour
1	Ground	Black
2	Not connected	
3	Not connected	
4	9 to 24V @ 200mA	White

## Truss-Ear Adaptor: *(Supplied separately)*


The Truss-Ear adaptor can be used to attach a DMX-Fix to a truss bar. To fit the Truss-Ear follow instructions below:

- 1) Remove two black end bezels
- 2) Unscrew two end plates
- 3) Push the DMX-Fix into the Truss-Ear
- 4) Using the eight screws provided, screw the side panels of the Truss-Ear into the DMX-Fix.



## Truss Mounting:

- 1) Attach a safety wire using the eye link provided (A)
- 2) Place over truss bar and screw the two thumb screws
- 3) There are additional holes for cable management (B)



## Input:

The DMX512 input is attached via a male 5 pin XLR.

## Loop Through:

A passive Loop Through connection allows onward connection to other DMX512 devices. If this feature is not required a termination link must be connected.

## Output:

Five DMX512 outputs are provided. Each output is capable of driving 32 additional DMX512 devices. It is not necessary to terminate any outputs that are not connected. However, a terminator must be connected to the final DMX512 device. If the DMX input fails DMX-Fix will automatically retransmit the last good DMX frame.

## Indicators:

Two dual colour indicators are provided:

1. Data:

- Green: Indicates that DMX512 is being transmitted by the outputs.
- Red: Indicates that DMX-Fix has fixed a bad packet.

2. Power:

- Red: Indicates good power and normal operation.

## System Connection:

The following table summarises the internal earth interconnection and isolation:

Please note that we use the term Earth-Ground to avoid international confusion. In Europe Earth-Ground is called Earth, in the USA Earth-Ground is called Ground.

Circuit	Description	
Chassis	Normally floating. Can be connected to Earth-Ground via screen of power cable.	
DMX512 Input (including Loop Through)	Type:	Isolated.
	Pin 1:	Connects to internal isolated circuit. No connection to chassis.
	Shell:	The connector shell is connected to chassis.
DMX512 Outputs	Type:	Grounded.
	Pin 1:	Connected to chassis.
	Shell:	The connector shell is connected to chassis.
Internal Logic Ground	Connects to chassis.	

## Accessories:

- ❑ DMX-Term5 - Termination Plug
- ❑ PSU-9-1.5-XLR4 - Moulded PSU with universal mains input via an IEC 3 pin
- ❑ Truss-Ear - A Truss Mounting Kit

### *Artistic Licence*

© Artistic Licence Engineering Ltd. 2007  
Studio 1 Spectrum House  
32-34 Gordon House Road  
London  
NW5 1LP  
UK  
Tel: +44 (0)20 88 63 45 15  
Fax: +44 (0)20 84 26 05 51  
Email: Sales@ArtisticLicence.com



The information contained in this document is subject to change without notice. Artistic Licence Engineering Ltd. makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of fitness for a particular purpose. Artistic Licence Engineering Ltd. shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material. All trademarks are acknowledged.